

P.č.	Kabel	Od	Do	Typ	Zily	Průřez	Délka (m)	Poznámka
1.	=R+RA1-WL0	+RK	=R+T-MXRA1					Stávající kabel
2.	=R+RA1-WL1	=R+RA1-X1	=R+RK-F N PE	CYKY-J	5	6	13	
3.	=R+RA1-WL2	=R+RA1-X2	=R+T-SB2	CYKY-J	3	2,5	16	
4.	=R+RA1-WL3	=R+RA1-XC	=R+RA1-X4	CYKY-J	3	2,5	30	
5.	=R+RA1-WL4	=R+RA1-X5	=R+T-MXEL	CYKY-J	3	1,5	20	
6.	=R+RA1-WL5	=R+T-MXEL	=R+T-S1	CYKY-J	3	1,5	20	
7.	=R+RA1-WL6	=R+T-MXEL	=R+T-EL1	CYKY-J	3	1,5	20	
8.	=R+RA1-WU1	=R+RA1	=R+T-HUS	CYA	1	10	15	
9.	=R+RA1-WU1.1	=+RA1 PE	=R+T-HUS	CYA	1	10	15	
10.	=R+RA1-WU2	=R+T-HUS	=R+T	CYA	1	6	15	
11.	=00+RA1-WD1	=00+T-K1	=04+RA1-N1	JYTY-O	2	1	10	
12.	=00+RA1-WD2	=00+T-K1	=00+T-K2	JYTY-O	2	1	6	
13.	=00+RA1-WD3	=00+T-K2	=00+T-K3	JYTY-O	2	1	6	
14.	=00+RA1-WL1	=00+MX-QS1	=00+RA1-X1	CYKY-J	3	1,5	8	
15.	=00+RA1-WL2	=00+RA1-X1	=00+T-HL1.1	CYKY-J	3	1,5	20	
16.	=00+RA1-WL3	=00+RA1-X1	=00+T-YV1	CYKY-J	3	1,5	25	
17.	=00+RA1-WL4	=00+RA1-X1	=00+T-K1	CYKY-J	3	1,5	10	
18.	=00+RA1-WL5	=00+RA1-X1	=00+T-K2	CYKY-J	3	1,5	9	
19.	=00+RA1-WL6	=00+RA1-X1	=00+T-K3	CYKY-J	3	1,5	8	
20.	=00+RA1-WL7	=00+RA1-X1	=00+T-BAP	CYKY-J	3	1,5	25	
21.	=00+RA1-WS1	=00+RA1-X2	=00+MX-QS1	JYTY-O	4	1	12	
22.	=00+RA1-WS1.1	=00+MX-QS1	=00+MX-QS2	JYTY-O	7	1	6	
23.	=00+RA1-WS1.2	=00+MX-QS3-X1	=00+MX-QS2	JYTY-O	7	1	6	
24.	=00+RA1-WS1.3	=00+T-QS1	=00+MX-QS1-X1	JYTY-O	7	1	6	
25.	=00+RA1-WS1.4	=00+T-QS2	=00+MX-QS2-X1	JYTY-O	7	1	6	
26.	=00+RA1-WS1.5	=00+T-QS3	=00+MX-QS3-X1	JYTY-O	7	1	6	
27.	=00+RA1-WS2	=00+RA1-X2	=00+T-PT1	JYTY-O	4	1	14	
28.	=00+RA1-WS3	=00+RA1-X2	=00+T-TT1	JYTY-O	4	1	18	
29.	=00+RA1-WS4	=00+RA1-X2	=00+T-LS1	JYTY-O	4	1	8	
30.	=00+RA1-WS5	=00+RA1-X2	=00+T-TT2	JYTY-O	4	1	8	

P.č.	Kabel	Od	Do	Typ	Zily	Průřez	Délka (m)	Poznámka
31.	=01+RA1-WL1	=01+RA1-X1	=01+T-Q2	CYKY-J	3	1,5	18	
32.	=01+RA1-WS1	=01+RA1-X2	=01+T-Q2	JYTY-O	2	1	18	
33.	=01+RA1-WS2	=01+RA1-X2	=01+T-Q2	JYTY-O	2	1	18	
34.	=02+RA1-WL1	=02+RA1-X1	=02+T-Q6	CYKY-J	3	1,5	20	
35.	=02+RA1-WS1	=02+RA1-X2	=02+T-Q6	JYTY-O	2	1	20	
36.	=02+RA1-WS2	=02+RA1-X2	=02+T-Q6	JYTY-O	2	1	20	
37.	=03+RA1-WL1	=03+RA1-X1	=03+T-Q20	CYKY-J	3	1,5	22	
38.	=03+RA1-WS1	=03+RA1-X2	=03+T-Q20	JYTY-O	2	1	22	
39.	=03+RA1-WS2	=03+RA1-X2	=03+T-Q20	JYTY-O	2	1	22	
40.	=04+RA1-WF1	=04+RA1-N1	=04+RA1-N2	AVS 82.490/109				
41.	=04+RA1-WF2	=04+RA1-N1	=04+RA1-OP1	AVS 82.491/109				
42.	=04+RA1-WF3	=04+RA1-N2	=04+RA1-N3	AVS 82.490/109				
43.	=04+RA1-WS1	=04+T-Y1/2	=04+RA1-N1	JYTY-O	4	1	20	
44.	=04+RA1-WS2	=04+T-B1	=04+RA1-N1	JYTY-O	2	1	20	
45.	=04+RA1-WS3	=04+T-B9	=04+RA1-N1	JYTY-O	2	1	20	
46.	=04+RA1-WS4	=04+T-B10	=04+RA1-N1	JYTY-O	2	1	20	
47.	=04+RA1-WS5	=04+T-Y5/6	=04+RA1-N2	JYTY-O	4	1	20	
48.	=04+RA1-WS6	=04+T-B12	=04+RA1-N2	JYTY-O	2	1	20	
49.	=04+RA1-WS7	=04+T-Y11/12	=04+RA1-N3	JYTY-O	4	1	20	
50.	=04+RA1-WS8	=04+T-B14	=04+RA1-N3	JYTY-O	2	1	20	
51.	=04+RA1-WS9	=04+RA1-X_MBUS	=04+T-FIQ1	JYTY-O	2	1	20	
52.	=04+RA1-WS10	=04+RA1-X_MBUS	=04+MX-FIQ2-X1	JYTY-O	2	1	20	